



THROTTLESYNC™

an **enqenius design** brand

THROTTLESYNC™ INSTALLATION INSTRUCTIONS

1. Before installing THROTTLESYNC™, please verify you have all required components. The following parts should have been delivered to you:



- A. 1x Housing Assembly with red colored lever.
- B. 1x Receiving Housing
- C. 2x Stainless Steel Screws

2. Turn off both engines and remove keys.
3. Pull safety lanyard.
4. With both engines off, push the left throttle forward to gain access to the right throttle handle.



5. Remove upper screw of the RIGHT throttle lever with Phillips screw driver. **THIS IS THE ONLY SCREW OR PART THAT NEEDS TO BE REMOVED.**



Make sure to save the star washer that will come off with the screw.





THROTTLESYNC™

an **enqenius** design brand

THROTTLESYNC™ INSTALLATION INSTRUCTIONS

6. Choose the correct housing assembly that will be installed to the RIGHT throttle handle. You have the option to install Housing A (with red colored lever) on either side, depending on your preference:



7. Slide the preferred housing assembly over the RIGHT existing throttle handle until it fits snug. **DO NOT REMOVE ANY ORIGINAL PLASTIC PARTS. THE THROTTLESYNC HOUSING ASSEMBLY FITS OVER THE EXISTING HANDLE!** In the following picture I chose to install the Receiving Housing B on the RIGHT lever handle:





THROTTLESYNC™

an **enqenius design** brand

THROTTLESYNC™ INSTALLATION INSTRUCTIONS

8. Take one of the 20mm long large head screws (included) and the previously removed star washer. Insert both into the bore and carefully tighten using a screw driver. **DO NOT OVERTIGHTEN.**



-
9. Repeat steps 5 through 8 to the LEFT throttle lever.





THROTTLESYNCTM

an **enqenius design** brand

THROTTLESYNCTM INSTALLATION INSTRUCTIONS

10. The installation is complete. Make sure both included screws are hand tight and the housing assemblies are tightly fitted.



.....

11. Put both levers back to NEUTRAL. Re-attach the lanyard.

Enjoy the **THROTTLESYNC**TM

